



SINC2B230B



1.88" x 11.38" x 20.5" (H x W x D)

ENERGY STAR certified 3600W 208-240V 12" wide 2-zone built-in induction cooktop with a jet black glass surface, touch controls, and power boost

Highlights:

3600W of cooking power with boost functions for both elements

Advanced safety features include automatic shutoff, overflow protection, child lock, and residual heat indicator light

Jet black glass surface offers a modern look that's easy to clean

Product Features:

230V 2-Burner Induction Cooktop	Smooth-top glass cooktop ideal for hotels, apartments, and other small kitchen spaces
ENERGY STAR certified	Rated by the DOE to perform with more efficiency than federal standards require, saving your unit energy and you on higher utility costs
Induction heating	Electromagnetic heating technology where heat is generated inside your cookware, ensuring a more efficient process with less energy waste, faster heating, and a safer cooking experience
3600W operation	Powerful elements with fast heating to meet most stovetop cooking needs
Jet black glass surface	Elegant style on a smooth, jet black glass surface for a contemporary look that is easier to clean
Large rear element	8 1/4" element operates at 2000W (with a 2600W capacity at the boost setting) for fast, powerful heating
Standard front element	6 1/4" front element operates at 1500W (or 2000W using boost) to cover most general cooking needs
Boost function	Both cooking zones include a "boost" function that lets them operate at a higher setting for up to 5 minutes, ideal for reducing cook time when boiling water

Timer function Allows you to program either burner to heat at a specified level for up to 99 minutes and either turn off when finished or display countdown with an audible alert when the time expires



SINC2B230B Specifications:

Overview	
Nominal Height	1.88" (5 cm)
Height of Cabinet	1.88" (5 cm)
Nominal Width	12.0" (30 cm)
Width	11.38" (29 cm)
Nominal Depth	21.0" (53 cm)
Depth	20.5" (52 cm)
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	15.0
Voltage/Frequency	240 V AC/60 Hz
Weight	14.0 lbs. (6 kg)
Parts & Labor Warranty	1 Year
UPC	761101083520
Induction Cooktop	
Application	Built-in
Heating Type	Induction
Surface	Glass
Number of Elements	2
Controls	Digital
Cooking Timer	Yes
Countertop Cutout Width	10.63" (27 cm)
Countertop Cutout Depth	19.63" (50 cm)
Power Source	208-240V
Element #1 Size	6.25
Element #1 Wattage	1500.0
Element #2 Size	8.25
Element #2 Wattage	2000.0
Power Cord Included	No

