



SINC5B36B



2" x 35.5" x 20.5" (H x W x D)

10200W 208-240V 36" wide 5-zone built-in induction cooktop with a jet black glass surface, touch controls, and power boost

Highlights:

Advanced safety features include automatic shutoff, overflow protection, child lock, and residual heat indicator light

10200W of cooking power with boost functions for all elements

11" center element handles oversized cookware with plenty of room

Product Features:

Induction heating	Electromagnetic heating technology where heat is generated inside your cookware, ensuring a more efficient process with less energy waste, faster heating, and a safer cooking experience
10200W operation	Powerful elements with fast heating to meet most stovetop cooking needs
Jet black glass surface	Elegant style on a smooth, jet black glass surface for a contemporary look that is easier to clean
11" extra large center element	Ideal when cooking with woks or other oversized cookware, the 11" wide center zone functions at 2300W in normal operation or 3000W when using boost
2 large elements	8 1/4" elements in the front left and rear right operate at 2000W (with a 3000W capacity at the boost setting) for fast, powerful heating
2 standard elements	6 1/4" front right and rear left elements operate at 1500W (or 2000W using boost) to cover most general cooking needs
Smart burner layout	Largest elements are located diagonally, with maximum spacing to allow large cooking vessels in use simultaneously
Boost function	All cooking zones include a "boost" function that lets them operate at a higher setting for up to 5 minutes, ideal for reducing cook time when boiling water



Allows you to program either burner to heat at a specified level for up to 99 minutes and either turn off when finished or display a countdown with an audible alert when the time is up



SINC5B36B Specifications:

Overview	
Nominal Height	2.0" (5 cm)
Height of Cabinet	2.0" (5 cm)
Nominal Width	36.0" (91 cm)
Width	35.5" (90 cm)
Nominal Depth	21.0" (53 cm)
Depth	20.5" (52 cm)
Cabinet	Black
US Electrical Safety	ETL
Canadian Electrical Safety	ETL-C
Amps	50.0
Voltage/Frequency	240 V AC/60 Hz
Weight	40.0 lbs. (18 kg)
Parts & Labor Warranty	1 Year
UPC	761101077635
Induction Cooktop	
Application	Built-in
Heating Type	Induction
Surface	Glass
Number of Elements	5
Controls	Digital
Cooking Timer	Yes
Countertop Cutout Width	34.63" (88 cm)
Countertop Cutout Depth	19.63" (50 cm)
Power Source	208-240V
Element #1 Size	8.25
Element #1 Wattage	2000.0
Element #2 Size	6.25
Element #2 Wattage	1500.0
Element #3 Size	11.0
Element #3 Wattage	2300.0
Element #4 Size	8.25
Element #4 Wattage	2000.0
Element #5 Size	6.25
Element #5 Wattage	1500.0
Power Cord Included	No

